Regular Expressions

The art of pattern matching

 $m/ATGA\{4,7\}T(C|A)AAG?TAA/ig$ m/L(D|S)Y?(L|C|I)agf+L?DG.g/i $m/^contig-\d\{1,\}\taugustus_masked\tmatch_part\t(\d\{1,\})\t(\d\{1,\})\$



POSIX† vs. Perl

SRE/BRE/ERE: <u>Simple/Basic/Extended Regular Expressions</u>
Perl implementation
grep -P 'regxep' *.files

A few tips...

Be specific but not overly so Always verify the output Practice makes perfect

Start simple, then complexify if required
Regexes may not behave the way you thought
The difficulty often resides in finding the patterns

Online regex testers

Online real-time regular expression testers

http://regexr.com/

My favorite

http://regexpal.com/

https://regex101.com/

Copy & paste

Copy the content of Regexp.txt
We'll use this file for the following slides
Use an online regex tester to practice

Regexp.txt is available in Blackboard

Characters – Regular vs. Meta

Regular characters are taken literally

Meta characters have special meanings

The basics

0-9 Numbers

a-z, A-Z Alphabet (case sensitive)

. Any character (except newline)

The basics – part II

```
\d Digits (numbers)
\w Words (0-9, a-z, A-Z, _); i.e. alphanumeric
```

\s Space (any whitespace)

The opposites

Capital letters indicate the opposite of (everything but)

\D Non-digits

\W Non-words

\S Non-whitespace

The quantifiers

- * Zero or more
- + One ore more
- ? Zero or one (*i.e.* optional)
- {X,Y} Specific range

Anchors

- ^ Matches at the start
- \$ Matches at the end

Boundaries

\bword\b Full word

\bword Word starts with

word\b Word ends with

\Bword\B Not a boundary word

Other essentials

\t Tab

\n Newline

The alternative

```
(a|b) a or b
(a|t|g|c) a, t, g or c
[atgc] a, t, g or c ## Simpler with multiple characters
```

Backslashing – the art of escaping

Converts meta to regular characters in searches

//

\^

\\$

The parentheses – Storing values

Assign values for Perl to remember

m/^ATG(\w{3})TAT(\w{3})AAA(GAG)/ \$1 \$2 \$3

TIMTOWTDI

There Is More Than One Way To Do It - Perl's motto

grep -P 'regex' input(s) > output

A bit of Perl, without Perl

The -P switch invokes Perl regex mode

diff – compare files line by line

Checking for differences between files

```
diff my_output.txt expected_output.txt
diff -s my_output.txt expected_output.txt
```

```
## 1<sup>st</sup> file = < ; 2<sup>nd</sup> file = >
## -s returns a message if identical
```

```
BLASTN 2.2.24+
4 Reference: Stephen F. Altschul, Thomas L. Madden, Alejandro A.
5 Schaffer, Jinghui Zhang, Zheng Zhang, Webb Miller, and David J.
6 Lipman (1997), "Gapped BLAST and PSI-BLAST: a new generation of
7 protein database search programs", Nucleic Acids Res. 25:3389-3402.
Database: allContigs.fasta
  ······319·sequences; ·2,408,894·total·letters
16 Query= selected bases
17 Length=15922
    producing significant alignments:
                           (Bits)
                             ·Value
  Hsw1la allContigs.ace.1 (whole contig) .....
                           3636.
  Hsw1lb allContigs.ace.1 (whole contig) .....
                           2242
  Hsw1lc · allContigs.ace.1 · (whole · contig) · · · · · · · · ·
                           · · 181
                          ...147
24 lcl contig-25000000 allContigs.ace.1 (whole contig) .....
  Hswu3 allContigs.ace.1 (whole contig) .....
26 lcl Hsw1) allContigs.ace.1 (whole contig) ......48.2
42 lcl Hsw0
     43 lcl Hsw0
 >lc. | Hsw la allContigs.ace.1 (whole contig)
47 Length=25723
```

Exercise 1 – From simple to complex

- 1) Grep all lines containing Hsw
- 2) Grep lines with score (bits) > 100
- 3) Grep lines with Evalue < 1e-10</p>
 ## This one can be quite
 ## complicated! You can skip it and
 ## do the other exercises first

```
ECU01 0010 ECU0
                          undefined product 4117:4593 forward MW:16919
  MPHTGSQHTLQATPKTAQ
                          STRVEGECSSDGVVMMFCMPARGEEEKASGEARGEDV
  GSSRESROGTAHKSTCMHTEAASI
                                ned product 4391:5086 reverse MW:25357
                                CFPARLLLLCCSFSARLLLLCCSFSARLLLL
9 AMPLLCACMCSYVLCPAATLSTSRRPPLLPRQRPFLLLPSPACRTSSRRHH
10 >ECU01 0030 ECU01 0030 undefined product 11158:11529 reverse MW:13491
11 MDVCTITGMTARGRLRVSRSSRWCWVQGGGMYMATRLGCIQREMCEGAVSGLWEEGEDGG
12 TRTQMGKRAREVGLEEGVLLLWRTLDLGGVGGRKLGSEGQSLSENSEQRSLMRWGCGGSS
14 >ECU01 0040 ECU01 0040 undefined product
                                                  :13003 forward MW:22950
15 MCKDRQHTSRPQIQHNRVKTPLAKLTSTIAKGPLHKKSTMGF
16 IIPCKTRTYSTVSETAWRQTNPSPNELLLSMLPPVPRRPRGGCRPLHAPLLNKMPQTFPA
17 ASERPMPSRRLSKATONVOTRPSERPAPCHRRPGPRGPGGRDPPEACHPWSLGPELGLLA
18 PSEVQFDCLEASRTWNTFIGAYTK
19 >ECU01 0050 ECU01 0050 undefined product 13837:14457 forward MW:22743
20 MPRPASHLAPMPSDHPDFRSKSARLRCQPPRTNNCGTFKQPPSVAATSRPKPGNPFLQPP
21 TKGTPPPKKKKKNHTEGCHTHEANPEPNTKHTETESPKPQTSTQHHTPITIPSSLLSQNT
22 QREKRGLPLLTSRPSTIPANTYQPQSPHIHSHTPLQRPISTALLHQNLHIRARNIRHTGR
23 LHGSPTKGAQTAQQAQPHPPKQLATL
24 >ECU01 0060 ECU01 0060 undefined product 14529:14834 reverse MW:10709
25 MRSISVGLDREESGSDGLCLGLVVLATLAAGFVAGSDVLRCWGFGPATGDVCLWVEAGFW
26 RCPLPGGGADGQGPGFWDAALREARMFCRSCVGLRMIGWRR
27 >ECU01 0070 ECU01 0070 undefined product 15893:16657 forward MW:28717
28 MNITHVPEIHRTDKOHTENLRHWRKILGIAPFVSIVFPAIMYFISDEDSFKKSLLLRFIT
29 ILLPFSYSAVQYAILLHTTPYYTLNLLFLAFAAISILSITALPINEWKGDDSLIFSIVLP
30 SLFIPPTYLLSTSCRLVPGQTAFTDTGINVLIDILILLCPLVSLVLVCKEPEYRLLSAVP
31 FPILILARLLNDRYCPSEKSAPPTAPWRVAILVLILTSAALIYAFMMWTPIAILNGYFGL
32 LHKLRESFLSLRPD
33 >ECU01 0080 ECU01 0080 undefined product 17534:18529 reverse MW:37889
34 MRRIYAAWTLVAAAGVMDCSPRLEKAAAFTLGPDSQVIVFPFMFQGYNIAVLPTTKYGDL
35 KGNARRRVASFLEHNISHAVWYFVVGGIAYKDDRSERLFSEMMDGYLKKISAGASKVYKG
36 GRKMFSESLETVHEMIFECNKAGDGHVVKYGKSIINRLSDMIENALGEVSAEEKRKYRRF
37 WSRVKERAGFLYSTERLRRVVEAEKIVCNACKEICLELEEEELMGLLAEGSVRKALKAKV
38 DEDEISRGLYLECTVVNTSLLLDAHREHGGDVTRELVKQMLLGKKGEEIDRRYINKVANV
39 VKERQRSEMEKRDREQDPERRRLRARRVGSL
40 >ECU01 0090 ECU01 0090 undefined product 19172:20002 forward MW:30326
41 MGIIDVQRSHLTATPSKERDAPAHPPPTILPVCILFPYTSIALPVLMYYIPEKGQFDQNP
42 FLKLIAILPPCLYSAVOFPLLFLGNPESSCTPRPALYATLYLLLDASLLAFSAISILSIA
43 AFTTTEWNSDEVVAVCSTLLPSLLVLPAHLLSTSCALTPGSIGFTDSSVDILIDLLMVSL
44 LAAGLTLNVDESWRFFPYICISSLVLVLAKLLRKSSSMPRRDPAPAPAWRIAAFVLIFGL
45 SMFVYFSILYECLLIFGNHFPWFPSQAPSNDLTNKW
46 >ECU01 0100 ECU01 0100 undefined product 20249:22108 reverse MW:72282
47 MGSVHGWIAWGGGLHGSDVEESEGMKKVRKVLEKAFSRKLYDSEVERIRTFEKELCLDTR
48 VMIPFIFHGDRVVALPTTRYQDVDKSEKKYVEGVVMQLRRLVWRLMVWMHVPGGSSWIES
49 LINEVFEATVSRDSDPVSLYKGARRRSGIRLMDLVMEVFKQNVSMVSEFGQRLARSAEDR
50 MOGIPGSLSPEERKKEEEMLWKIKEHGERLCTKEROEEMVRAOKIICDVCAYVWEKDEDR
52 KGIDDESINNAVREVRERKRLEEMREMEERKRREEERAKNEEELLRMVEREEREKREKRE
  KREESKGRGKRGAGEAKEESKEEDGKEEEGVEAEEEESAEVDLVETAVGGARRKKSLKGK
```

Exercise 2 – Boundaries

- Grep all words containing ECU
- 2) Grep only complete words starting with ECU and ending with 0
- 3) Notice something odd? ## Yep, \w+ does not capture >, only letters, digits and underscores
- Grep undefined bounded left, product bounded right

```
2 cp ROM/ROM ECU05 0085.fsa ./
 3 cp GBM1/GBM1 ECU05 0435.fsa ./
 4 cp GBM1/GBM1 ECU05 0495.fsa ./
 5 touch OC4 ECU05 0495.fsa
 6 nano OC4 ECU05 0495.fsa
 7 cp GBM1/GBM1 ECU05 0885.fsa ./
11 tblasn - query lookCH01.fasta - db DB/c01 - outfmt 0 out lookCH01.tblastn
12 tblastn -query lookCH01.fasta -db DB/c01 -outfmt 0 out lookCH01.tblastn
13 tblastn -query lookCH01.fasta -db DB/c01 -outfmt 0 -out lookCH01.tblastn
14 tblastn - query GBM1 ECU02 0355.fsa - db DB/c02 - outfmt 0 - out 0355.tblastn
15 tblastn -query GBM1 ECU03 0305.fsa -db DB/c03 -outfmt 0 -out 0305.tblastn
16 tblastn -query ECI ECU03 1115.fsa -db DB/c03 -outfmt 0 -out 1115.tblastn
17 tblastn - query ROM ECU03 0375.fsa - db DB/c03 - outfmt · 0 - out · ROM.tblastn
18 tblastn - query · lookch4.fasta · -db · DB/c04 · -outfmt · 0 · -out · ch4.tblastn
19 tblastn -query ROM ECU05 0085.fsa -db DB/c01 -outfmt 0 -out 0085.tblastn
20 tblastn - query ROM ECU05 0085.fsa - db DB/c05 - outfmt 0 - out 0085.tblastn
           -query GBM1 ECU05 0435.fsa -db DB/c05 -outfmt 0 -out 0435.tblastn
            -query GBM1 ECU05 0435.fsa -db DB/c01 -outfmt 0 -out 0435.tblastn
22 tblastn.
23 tblastn.
            -query GBM1 ECU05 0495.fsa -db DB/c01 -outfmt 0 -out 0495.tblastn
            -query GBM1 FCU05 0885.fsa -db DB/c01 -outfmt 0 -out 0885.tblastn
24 tblastn.
            -query GBM1 FCU05 0885.fsa -db DB/c05 -outfmt 0 -out 0885.tblastn
  ln -s/run/media/Jeff/Data/Linux/Organisms/Ordospora/illumina/Sickle/Acnes removed/split/L1.fa
           un/media/Jeff/Data/Linux/Organisms/Ordospora/illumina/Sickle/Acnes removed/split/L2.fa
                 ia/Jeff/Data/Linux/Organisms/Ordospora/illumina/Sickle/Acnes removed/split/L3.fa
                 ia/Jeff/Data/Linux/Organisms/Ordospora/illumina/Sickle/Acnes removed/split/L4.fa
                 ia/Jeff/Data/Linux/Organisms/Ordospora/illumina/Sickle/Acnes removed/split/L5.fa
           un/media/Jeff/Data/Linux/Orqanisms/Ordospora/illumina/Sickle/Acnes removed/split/R5.fa
           un/media/Jeff/Data/Linux/Organisms/Ordospora/illumina/Sickle/Acnes removed/split/R4.fa
           un/media/Jeff/Data/Linux/Orqanisms/Ordospora/illumina/Sickle/Acnes removed/split/R3.fa
           un/media/Jeff/Data/Linux/Orqanisms/Ordospora/illumina/Sickle/Acnes removed/split/R2.fa
           un/media/Jeff/Data/Linux/Organisms/Ordospora/illumina/Sickle/Acnes removed/split/R1.fa
42 makeblastdb -in Edhazardia aedis USNM41457 proteins.fasta -dbtype prot -out Edhazardia
43 makeblastdb -in Encephalitozoon cuniculi ECII-CZ proteins.fasta -dbtype prot -out ECII CZ
44 makeblastdb - in Nosema bombycis CQ1 proteins.fasta - dbtype prot - out Nosema bombycis
45 makeblastdb -in Nosema ceranae proteins.fasta -dbtype prot -out Nosema ceranae
46 makeblastdb -in Vavraia culicis floridensis proteins fasta -dbtype prot -out Vavraia culicis
47 makeblastdb -in Vittaforma cornea
                                          C50505 proteins.fasta -dbtype prot -out Vittaforma corne
48 makeb astdb -in Encephalitozoon
                                         li ECIII proteins.fasta -dbtype prot -out EC EC3
                                    cunredli ECII proteins.fasta -dbtype prot -out EC EC2
         .astdb -in Encephalitozoon
50 makeb astdb -in Encephalitozoon
                                   cuniculi ECI proteins.fasta -dbtype prot -out EC EC1
   makeb astdb -in Encephalitozoon
                                    cuniculi GBM1 proteins.fasta -dbtype prot -out EC GBM1
   makeb<mark>astdb -in Encepha</mark>litozoon hellem ATCC50504 proteins.fasta -dbtype prot -out Hellem HEL
53 makeb astdb -in Encephalitozoon hellem Swiss proteins.fasta -dbtype prot -out Hellem KMI
```

Exercise 3 – Start/end lines

- 1) Grep only lines ending with tblastn
- Grep only lines ending with tblastn and query starting with GBM1
- 3) Grep lines starting with In -s
- Grep all lines starting with make and containing Encephalitozoon

```
1 >Feature pelago.fsa
               gene
                       psbA
               gene
 4 1062
               CDS
                       psbA
               gene
               product photosystem II Q(b) protein (D1)
7 1228
                       tRNA-Arg(ccg)
               gene
 9 1228
           1301
                   tRNA
                       tRNA-Arg(ccg)
               gene
               product tRNA-Arg
12 1314
                   gene
14 1314
           1635
                   tmRNA
               gene
                        tag peptide ANNILKFFTKSPVVAFA
17 1649
           1732
                       tRNA-Met
               gene
19 1649
                   tRNA
               product tRNA-Met
               gene
                       clpC
24 1808
           4309
                   CDS
               product ATP-dependent clp protease ATP-binding subunit
27 4526
               gene
                       petN
29 4526
           4615
                   CDS
                       petN
               product cytochrome b6-f complex subunit VIII
                       petM
34 4689
                   CDS
               product cytochrome b6-f complex subunit VII, petM
37 5117
                        tRNA-Cys (gca)
               gene
39 5117
                   tRN
                       tRNA-Cys(gca)
               gene
               product tRNA-Cys
42 5203
                       tRNA-Leu(taa)
               gene
   5203
                   tRNA
                       tRNA-Leu(taa)
               gene
               product tRNA-Leu
47 5792
                       ilvH
               gene
49 5792
           5286
                   CDS
               product acetolactate synthase small subunit
52 6791
                   gene
               gene
                     petA
```

Exercise 4 – The great escape

- 1) Grep all lines containing (cat), get the parentheses too
- 2) Grep all lines containing tRNA-something(anticodon)
- 3) Can you find the error in those lines? Think biology
- 4) Grep lines for which with third digit is a zero

1 atpA 3 BRYOplumo MVK---IRADEISSIIRQQIEQYNQEVKVVNIG 4 DERBmarin MVK---IRPDEISSIIRQQIEQYNQEIKVINVG 5 NEOCpseud MVK---IRPDEISS DOIEOYNOEVKVVNVG 6 PEDIminor VK---IRPIEISS QQIEQYTQEVKVVNVG MVK---IRPDEISSIIKRQIEQYNRDVKVVNVG 7 SCHEdubia E CFLOvulca MVK---IRPDEISSIIKQQIEQYQQEVKAVNVG 9 OLTMviria MVK---IQPDEISSIIRQQIEQYSQEVKVVNVG 10 PSEUakine MVK---IQPDEISSIIRQQIAQYSEEVKVVNVG 11 SCENobliq MSM---RTPEELSNLIKGLIEEYTPEVKMVDFG 12 CHLAreinh MAM---RTPEELSNLIKDLIEQYTPEVKMVDFG 13 MESOvirid MIK---IOPEEISSVIRKOIEOYNOEVKVVNTG MIK---IQPEEISSVIRKQIEQYNQEVKVVNIG 14 CHLOatmop 15 STAUpunct MVN---IRPDEISSIIRKQIEQYNQEVKVVNIG 16 CHAEglobo MVN---IRPEEISSIIRKQIEQYNQEVRVINIG 17 CHARvulga MVSNIGIRPAEISSIIRKKIEEYDQEVKIVNIG 18 EUGLgraci MIR---VRPNEVTRIIRQQVKKYRQELKIVNVG 19 MONOaenig MVK---IRPNEVSRIIRQQIEKYNQELKVVNVG 20 EUTRvirid MVK---IRPDEISSIIRQQIKQYNQQVRFVNVG MVK---IRPDEISSIIRQQIEQYNQEVKVVNVG 21 EUTRgymna 22 MONOoke-1 MVK---IRPDEISSIIRQQIESYNQEVKISNVG 23 NEPHoliva MVK---IRPDEISNIIRQQIEQYSQEVKVVSVG 24 PYCNpraso MVK---IRPDEISSIIRKOIESYTNEIEVENVG . *:: :*: : .* ::. . 26 27 BRYOplumo

28 DERBmarin 29 NEOCpseud

30 PEDIminor

31 SCHEdubia

32 CHLOvulga

33 OLTMvirid

34 PSEUakine

35 SCENobliq

36 CHLAreinh

37 MESOvirid 38 CHLOatmop

39 STAUpunct

40 CHAEglobo

41 CHARvulga

42 EUGLgraci

AIAVDTILNQKGKGVICVYVAIGQKASSIAQVV AIAVDTILNOKGKDVICVYVAIGOKASSIAOVV AVAVDTILNQKGKDVICVYVAIGQKASSIAQVV AVAVDTILNQKGKGVICVYVAIGQKASSIAQVV AIAVDTILNQKGNGVICVYVAIGQKASSIAQVV AIAVDTILNQKGKDVVCVYVAIGQKASSIAQVV AIALDTILNQKGNGVICVYVAIGQKASSIAQVV AIAVDTIINQKGKDVICVYVAIGQKASSIAQVV AIAVDTILNQKGKGVICVYVAIGQKASSVAQVL AIAVDTILNOKGKGVICVYVAIGOKASSVAOVL AVAIDTILNQKGQNVICVYVAIGQKASSVAQVV AVATDTILNQKGQNVICVYVAIGQKASSVAQVV AVATDTILNQKGQNVICVYVAIGQKASSIAQVI AVATDTILNQKGNNVICVYVAIGQKASSVAQVL AVAVDTILNQKGQDVICVYVAIGQKASSVAQVV AVATDTILNQKGQGVICVYVAIGQKASSVSQIV

Exercise 5 — Another iteration

- 1) Return sequences with K in 3rd position
- Return sequences with K or S in 3rd position and I in 9th ## not counting dashes (---)
- 3) Return names starting with C or O and ending with a or d

```
2 RN
        DOI; 10.1093/nar/21.15.3537.
        PUBMED; 8346031.
 5 RA Hallick R.B., Hong L., Drager R.G., Favreau M., Moniort A., Orsat B.,
       Spielmann A., Stutz E.;
        "Complete sequence of Euglena gracilis chloroplast DNA";
        Nucleic Acids Res. 21(15):3537-3544(1993).
 9 XX
                         complement (115617..115732)
13 FT
14 FT
                         /gene="5S rRNA"
                         /product="5S ribosomal RNA"
15 FT
                         /note="rrnC"
                         complement (115817..118693)
                         /gene="23S rRNA"
                         /product="23S ribosomal RNA"
                         /note="rrnC"
        tRNA
                         complement (118718..118790)
                         /gene="tRNA-Ala"
                         /product="transfer RNA-Ala"
                         /anticodon=(pos:118755..118757,aa:Ala)
                         /note="tRNA-Ala in rrnC"
        tRNA
                         complement (118800..118873)
27 FT
                         /gene="tRNA-Ile"
28 FT
                         /product="transfer RNA-Ile"
29 FT
                         /anticodon=(pos:118837..118839,aa:Ile)
                         /note="tRNA-Ile in rrnC"
30 FT
                         complement(join(2171..3152,3485..3549))
                         /transl table=11
                         /gene="ccsA"
                         /product="CcsA protein"
34 FT
                         /db xref="GOA:P31205"
35 FT
                         /db xref="InterPro:IPR000523"
37 FT
                         /db xref="InterPro:IPR003593"
38 FT
                         /db xref="InterPro:IPR011775"
                         /db xref="UniProtKB/Swiss-Prot:P31205"
39 FT
40 FT
                         /protein id="CAA50075.1"
41 FT
                         translation="MNKKTNERPVFPFTSIVGQEEMKLSLILNVIDPKIGGVMIMGDRG/
42 FT
                         TGKSTIVRALVDLLPPIDVIENDPYNSDPYDTELMSDDVLEKIKKNEKVSIIOVKTPMV
43 FT
                         VDGLRGDMVTSRAAKALVAFEDRTEVTPKDIFTVITLCLRHRLRKDPLESIDSGYKVQE
                         TFKKVFNY"
48 FT
                         1..143171
                         /organism="Euglena gracilis"
                         /organelle=plastid:chloroplast
                         /strain="Z"
52 FT
                         /mol type="genomic DNA"
53 FT
                         /db xref="taxon:3039"
```

Exercise 6 – EMBL

- 1) Return CDS, tRNA and rRNA gene features in one command
- 2) Return author names (hint: look at the file structure)
- 3) Return strain

```
all bases
                                                                  all bases
                                                                  all bases
                                                                               31253
 hwi-st765:86:D0AA7ACXX:5:2308:18082:178550 2:N:0:CTTGTA/2
                                                                  all bases
                                                                              31409
 HWI-ST765:86:DOAA7ACXX:5:2308:18031:178706 2:N:0:CTTGTA/2
                                                                  all bases
                                                                              15686
                                                                  all bases
                                                                              62129
                                                                  all bases
                                                                              62230
                                                                  all bases
                                                                               37420
 HWI-ST765:86:D0AA7ACXX:5:2308:12332:200403
HWI-ST765:86:D0AA7ACXX:5:2308:12332:200403 2:Y:0:CTTGTA/2
                                                                  all bases
                                                                              37480
                                                                  all bases
HWI-ST765:86:D0AA7ACXX:5:2308:18130:178544 1:N:0:CTTGTA/1
                                                                                 3
HWI-ST765:86:D0AA7ACXX:5:2308:18130:178544 2:N:0:CTTGTA/2
                                                                  all bases
                                                                  all bases
 HWI-ST765:86:DOAA7ACXX:5:2308:18082:178550 1:N:0:CTTGTA/1
HWI-ST765:86:D0AA7ACXX:5:2308:18082:178550 2:N:0:CTTGTA/2
                                                                  all bases
                                                                               31409
HWI-ST765:86:D0AA7ACXX:5:2308:18031:178706 2:N:0:CTTGTA/2
                                                                  all bases
HWI-ST765:86:D0AA7ACXX:5:2308:18031:178706 1:N:0:CTTGTA/1
                                                                  all bases
HWI-ST765:86:D0AA7ACXX:5:2308:19482:178689 1:N:0:CTTGTA/1
                                                                  all bases
```

Exercise 7 – Sequences

- 1) Grep all sequence names ending with /2
- 2) Grep all sequence names containing 2308:11393:200493
- 3) Grep sequences starting with AG and ending with TA

Self practice

Free time to practice by yourself

Use any text file you want

I'll hang around to answer your questions